



Note: Add 0.1 μF close to Q1 collector and across power terminals

For reverse voltage protection add 1N5818 diode as shown

** Adjust value as needed for required offset, e.g., 800 Hz

For experimenting, use DIP/SIPP pins as sockets
Q2, **82 pF and 100 pF(2).

Lil' Squall

W5USJ Drawing 6 Mar 2011