

COPPER  
VIEW



Notice that square pads and round pads are very close but do not touch. You can easily solder across the pads or carefully keep them separated so that you can make your own custom pinout for the module. You can also use straight male headers for a .6" wide DIP module or right angle male headers for a SIP module to save space on a solderless breadboard.

2 rows of pads with .1" spacing  
.07" pads .04" holes .6" on centers  
for mounting male SIP headers  
so the MePad can be used on  
solderless breadboards.